



## Part 3 of 3




ZOOM

SIZED FOR PRINT




ZOOM

SIZED FOR PRINT




ZOOM

SIZED FOR PRINT




ZOOM

SIZED FOR PRINT



ZOOM

SIZED FOR PRINT



ZOOM

SIZED FOR PRINT

**REASSEMBLY****NOTICE:**


- The automatic transaxle is composed of highly precision-finished parts, necessitating careful inspection before reassembly because even a small nick could cause fluid leakage or affect the performance. The instructions here are organized so that you will work on only one component group at a time. This will help avoid confusion from similar-looking parts of different sub-assemblies being on your workbench at the same time. The component groups are



inspected and repaired from the converter housing side. As much as possible, complete the inspection, repair and reassembly before proceeding to the next component group. If a defect is found in a certain component group during reassembly, inspect and repair this group immediately. If a component group cannot be assembled because parts are being ordered, be sure to keep all parts of that group in a separate container while proceeding with disassembly, inspection, repair and reassembly of other component groups. Recommended [ATF](#): TYPE T-IV or equivalent

- All disassembled parts should be washed clean and any fluid passages and holes should be blown through with compressed air.
- Dry all parts with compressed air-never use shop rags.
- When using compressed air, always aim away from yourself to prevent accidentally spraying [ATF](#) or kerosene on your face.
- The recommended automatic transaxle fluid or kerosene should be used for cleaning.
- After cleaning, the parts should be arranged in the correct order for efficient inspection, repairs, and reassembly.
- When disassembling a [valve body](#), be sure to match each valve together with the corresponding spring..
- New discs for the brakes and clutches that are to be used for replacement must be soaked in [ATF](#) for at least 15 minutes before reassembly.
- All oil seal rings, [clutch discs](#), clutch plates, rotating parts, and sliding surfaces should be coated with [ATF](#) prior to reassembly.
- All gaskets and rubber O-rings should be replaced.
- Do not apply adhesive cements to gaskets and similar parts.
- Make sure that the ends of a snap ring are not aligned with one of the cutouts and are installed in the groove correctly.
- If a worn bushing is to be replaced, the sub-assembly containing the bushing must also be replaced.
- Check thrust bearings and races for wear or damage. Replace if necessary. Use petroleum jelly to keep parts in place.
- When working with Formed In Place Gasket (**FIPG**) material, you must observe the following: Using a razor blade and a gasket scraper, remove all of the old packing from the gasket surface.

Thoroughly clean all components to remove all of the loose material. Clean both sealing surfaces with a non-residue solvent. Parts must be reassembled within 10 minutes of application. Otherwise, the packing Formed In Place Gasket (FIPG) material must be removed and reapplied.




ZOOM

SIZED FOR PRINT

30. INSTALL [DIFFERENTIAL](#) ASSEMBLY

31. INSTALL TRANSAXLE HOUSING



ZOOM

SIZED FOR PRINT

- a. Calculate the end play value using the following formula and values of Dimension D and E that were measured when installing cylindrical roller bearing and U/D planetary gear. Select an appropriate U/D planetary gear thrust bearing race No.2 which satisfies the specified end play value, and install it. End play: **0.198 - 0.693 mm (0.0078 - 0.0273 inch)** **HINT:** End play = Dimension E - Dimension D - Thrust bearing thickness 3.28 mm (0.1291 inch) - U/D [gear](#) thrust bearing race No.2 thickness

E - D	Thickness
Less than 7.42 (0.2921)	3.5 (0.138)
7.42 (0.2921) or more	3.8 (0.150)

ZOOM

SIZED FOR PRINT


Race thickness: mm (inch)

	Inside	Outside
Bearing	57.2 (2.252)	84.96 (3.3449)
Bearing race	56.4 (2.220)	83.0 (3.268)

ZOOM

SIZED FOR PRINT


Bearing and bearing race diameter: mm (inch)



ZOOM

SIZED FOR PRINT

- b. Install the [oil pump](#) and 7 bolts to the transaxle [case](#) Torque: **22 Nm (226 kgf-cm, 16 ft. lbs.)**




ZOOM

SIZED FOR PRINT




- c. Coat on O-ring of [oil pump](#) with [ATE](#).



ZOOM

SIZED FOR PRINT


- d. Remove any packing material and be careful not to get oil on the contacting surfaces of the transaxle [case](#) or transaxle housing.
- e. Apply FIPG to the transaxle [case](#). FIPG: Part No. 08826-00090, THREE BOND 1281 or equivalent



ZOOM

SIZED FOR PRINT

- f. Install the transaxle housing and 16 bolts to the transaxle [case](#). Torque: Bolt A: **22 Nm (226 kgf-cm, 16 ft. lbs.)** Bolt B and C: **29 Nm (300 kgf-cm, 22 ft. lbs.)** **HINT:** Apply seal packing or equivalent to the bolt A. Seal packing: THREE BOND 2403 or equivalent Bolt length: Bolt A: **50 mm (1.969 inch)** Bolt B: **50 mm (1.969 inch)** Bolt C: **42 mm (1.654 inch)** **NOTICE:** Because the bolt A is a seal bolt, apply the seal packing to new bolts and tighten them within 10 minutes after application.




ZOOM

SIZED FOR PRINT

32. INSPECT [INPUT SHAFT](#) END PLAY Using a dial indicator, measure the [input shaft](#) end play. End play: **0.27 - 1.24**

mm (0.0106 - 0.0417 inch)


33. CHECK [DIFFERENTIAL](#) PRELOAD (See page AX-107)



ZOOM

SIZED FOR PRINT


34. PLACE TRANSAXLE HOUSING  
35. INSTALL MANUAL VALVE LEVER SHAFT



ZOOM

SIZED FOR PRINT

- a. Coat the new oil seal with [ATE](#).  
b. Install the oil seal to the transaxle [case](#).




ZOOM

SIZED FOR PRINT

- c. Install the parking lock rod to the manual valve lever.






ZOOM

SIZED FOR PRINT


- d. Install a new spacer and manual valve lever shaft to the transaxle [case](#).



ZOOM

SIZED FOR PRINT

- e. Using a pin punch and a hammer, drive in a new pin.




ZOOM

SIZED FOR PRINT

- f. Turn the spacer and the lever shaft to align the small hole for locating the staking position in the spacer with the staking position mark on the lever shaft.  
g. Using a pin punch, stake the spacer through the small hole.  
h. Check that the spacer does not turn.






ZOOM

SIZED FOR PRINT


- i. Using needle-nose pliers, install the return spring.



ZOOM

SIZED FOR PRINT

- j. Install the parking lock pawl bracket with 2 bolts. Torque: **20 Nm (205 kgf-cm, 15 ft. lbs.)** Bolt length: **25 mm (0.984 inch)**




ZOOM

SIZED FOR PRINT

- k. Install the manual detent spring with 2 bolts. **NOTICE:** Make sure to install the manual detent spring and cover in this order. Torque: Bolt A: **20 Nm (205 kgf-cm, 15 ft. lbs.)** Bolt B: **12 Nm (120 kgf-cm, 9 ft. lbs.)** Bolt length: Bolt A: **27 mm (1.063 inch)** Bolt B: **16 mm (0.630 inch)**





ZOOM

SIZED FOR PRINT

## 36. INSTALL ACCUMULATOR PISTONS AND SPRINGS


- Coat new 4 O-rings with [ATE](#) and install them to the pistons.
- Coat the 4 springs and 3 accumulator pistons with [ATE](#), install them to the holes.


Spring		Free length Outer diameter mm (in.)	Color
B <sub>3</sub>	Inner	60.24 (2.3716) / 15.9 (0.626)	Green
	Outer	72.61 (2.8587) / 16.7 (0.657)	Blue
C <sub>3</sub>		86.66 (3.4118) / 19.2 (0.756)	Yellow
C <sub>1</sub>		90.53 (3.5642) / 18.5 (0.728)	Red

ZOOM

SIZED FOR PRINT

Accumulator spring:






ZOOM

SIZED FOR PRINT

37. INSTALL CHECK BALL BODY AND SPRING


38. INSTALL TRANSAXLE SOLENOID WIRE



ZOOM

SIZED FOR PRINT


- a. Coat a new O-ring with [ATF](#), install it to the transaxle solenoid wire.




ZOOM

SIZED FOR PRINT

- b. Install the solenoid wire retaining bolt Torque: **5.4 Nm (55 kgf-cm, 48 inch lbs.)**








ZOOM

SIZED FOR PRINT

## 39. INSTALL APPLY GASKET

- a. Coat 4 apply gaskets with [ATF](#) and install them to the transaxle [case](#).



ZOOM

SIZED FOR PRINT

40. INSTALL [VALVE BODY](#) ASSEMBLY

- a. Align the groove of the manual valve with the pin of lever.
- b. Install the 17 bolts. Torque: **11 Nm (110 kgf-cm, 8 ft. lbs.)** **NOTICE:**
- Push the [valve body](#) against the accumulator piston spring and the check ball body to install It.
  - Tighten those bolts marked by \* in the illustration first temporarily because they are positioning bolts.

**HINT:** Each bolt length is indicated.

Bolt length:


Bolt A: **25 mm (0.984 inch)**

Bolt B: **41 mm (1.614 inch)**

Bolt C: **45 mm (1.771 inch)**

## 41. INSTALL OIL STRAINER






ZOOM

SIZED FOR PRINT


- a. Coat new gasket with [ATF](#), install it to the oil strainer.



ZOOM

SIZED FOR PRINT

- b. Install the oil strainer and 3 bolts to the [valve body](#). Torque: **11 Nm (110 kgf-cm, 8 ft. lbs.)**




ZOOM

SIZED FOR PRINT

- c. Connect the 5 solenoid connectors.  
d. Install the [ATF temperature sensor](#), lock plate and bolt. Torque: **6.6 Nm (67 kgf-cm, 58 inch lbs.)**

#### 42. INSTALL OIL PAN






ZOOM

SIZED FOR PRINT


- a. Install the 3 magnets in the oil pan.
- b. Apply seal packing or equivalent to the new 18 bolts. Seal packing: THREE BOND 2430 or equivalent



ZOOM

SIZED FOR PRINT

- c. Install a new gasket, oil pan and 18 bolts to the transaxle [case](#). Torque: **7.8 Nm (80 kgf-cm, 69 inch lbs.)** **NOTICE:** Because the bolts should be seal bolts, apply seal packing to new bolts and tighten them within 10 minutes after application.




ZOOM

SIZED FOR PRINT

#### 43. INSTALL SPEED SENSOR

- a. Coat new 2 O-rings with [ATF](#), install it to the 2 sensors.
- b. Install the 2 sensors with 2 bolts to the transaxle [case](#). Torque: **11 Nm (110 kgf-cm, 8 inch lbs.)**




ZOOM

SIZED FOR PRINT

## 44. INSTALL UNION

- a. Coat new 2 O-rings with [ATF](#), install them to the 2 unions.
- b. Install the 2 unions to the transaxle [case](#). Torque: **27 Nm (276 kgf-cm, 20 ft. lbs.)**




ZOOM

SIZED FOR PRINT

45. INSTALL TRANSAXLE [CASE](#) PLUG NO.1

- a. Coat a new O-ring with [ATF](#), install it to the transaxle [case](#) plug No. 1.
- b. Install the transaxle [case](#) plug No.1 to the transaxle case. Torque: **7.4 Nm (75 kgf-cm, 65 inch lbs.)**


46. INSTALL [PARK/NEUTRAL POSITION SWITCH](#)

ZOOM


SIZED FOR PRINT

- a. Install the [park/neutral position switch](#) onto the manual valve lever shaft and temporarily install the 2 adjusting bolts.


- b. Install the new nut stopper and nut. Torque: **6.9 Nm (70 kgf-cm, 61 inch lbs.)**

[ZOOM](#)[SIZED FOR PRINT](#)

- c. Temporarily install control shaft lever.


[ZOOM](#)[SIZED FOR PRINT](#)

- d. Turn the lever counterclockwise until it stops, then turn it clockwise 2 notches.  
e. Remove the control shaft lever.


[ZOOM](#)[SIZED FOR PRINT](#)

- f. Align the groove with neutral basic line.  
g. Tighten the 2 bolts. Torque: **5.4 Nm (55 kgf-cm, 48 inch lbs.)**



[ZOOM](#)[SIZED FOR PRINT](#)

- h. Using a screwdriver, stake the nut with the nut stopper.

[ZOOM](#)[SIZED FOR PRINT](#)

- i. Install control shaft lever, washer and nut. Torque: **6.9 Nm (70 kgf-cm, 61 inch lbs.)**